

Preface

Thank you for purchasing the SR Intelligent Controls Series (SR) of our company. You are recommended to take some time to read this manual, before putting the SR in to service. It tells you how to install, program and use the SR. The SR has, amongst many features, the advantage being able to be operated off line to prove in service performance before being commissioned into service. When you read the manual you will find many more advantageous properties of the products, it will greatly simplify the operation of SR for you.

The SR is a type of intelligent control, which uses function blocks for programming. It enables the control functions of a PLC to be achieved without the need for large number of instructions and complicated programming. When several function blocks are linked together in a specific way, relatively complicated control functions can be implemented. The programming can be carried out in a logical, speedy and verifiable manner. Programming can be implemented using a removable LCD liquid crystal display panel or by use of a computer. The latter approach is recommended for more complicated control schemes.

SR has a very wide range of applications. It can be used for the automation of an extensive range of electrical and mechanical equipment, flow control, building automation and many other fields. The implementation of SR provides for automation of many aspects of day-to-day life from home through to the commercial, manufacturing, mining, utility and service sectors of the economy. This manual will describe in detail the functional characteristics and operating methods for SR.

Notes:

Copyright of this manual and patent of SR Intelligent Controls Series are the property of MAXTHERMO-GITTA GROUP CORP The reproduction, transmission or use of this manual or its contents is not permitted without written express written authority.

Our company reserves the right to make changes in design for improvement SR Intelligent Controls Series without notification.

Suggestions for improvement are welcomed.

Safety Guidelines:

This manual contains notices which you should observe to ensure your own personal safety, as well as to product and connected equipment. These instructions in the manual are highlighted by a warning triangle and are marked as follows according to their danger level:

Danger

Indicates that death, severe harm to health or damage to assets will result if proper precautionary measures are not taken.

Caution

Indicates that death, severe harm to health or damage can result if the respective precautionary measures are not taken.

Warning

Draws your attention to particularly important information relating to the product and its handling, or to a part of the documentation requiring your special attention.

Notes

Only qualified personnel should be allowed to start and operate this device. Qualified personnel in the sense of the information on safety technology in this manual are persons who are authorized to commission, to ground and to tag circuits, equipment and systems in accordance with established safety regulations and standards.

Index

Part I Basic Operation and Application of SR

Chapter I General Introduction to SR

- 1.1 Structure of SR Series
- 1.2 Naming Rules of SR Series
- 1.3 Specifications and Model of SR Series
- 1.4 Features of SR

Chapter II Installing and Wiring of SR

- 2.1 Installing of SR
 - 2.1.1 Installing Methods
 - 2.1.2 Dimensions
- 2.2 Wiring of SR
 - 2.2.1 Connecting Power Supply
 - 2.2.2 Connecting Inputs
 - 2.2.3 Connecting Outputs
 - 2.2.4 Net-connecting SR Series

Chapter III General Description of SR Function Blocks

- 3.1 General Function Block (GF)
 - 3.1.1 AND
 - 3.1.2 AND with RLO Borderline Test
 - 3.1.3 OR
 - 3.1.4 NOT
 - 3.1.5 XOR
 - 3.1.6 NAND
 - 3.1.7 NAND with RLO Borderline Test
 - 3.1.8 NOR
- 3.2 Special Function Blocks (SF)
 - 3.2.1 TOND
 - 3.2.2 TOFD
 - 3.2.3 SPBL
 - 3.2.4 TPBL
 - 3.2.5 BLNK
 - 3.2.6 MTOD
 - 3.2.7 PONS
 - 3.2.8 UDCT
 - 3.2.9 CMPR
 - 3.2.10 T/C-CMPR
 - 3.2.11 SCHD

- 3.2.12 TSEQ
- 3.2.13 SSEQ
- 3.2.14 HOUR
- 3.2.15 Instructions of Property Pin
- 3.3 Input & Output Blocks
 - 3.3.1 IN
 - 3.3.2 OUT
 - 3.3.3 RCI
 - 3.3.4 DOUT
 - 3.3.5 D-IN
 - 3.3.6 PMSG
 - 3.3.7 CONT
 - 3.3.8 SLCD

Chapter IV Instructions of HMI Module

- 4.1 Comparisons with LCD of Conventional Controller
- 4.2 Application Example of HMI
- 4.3 Edition of the HMI
- 4.4 Instructions of Virtual Keys
- 4.5 Password Setup
- 4.6 Instruction of Help in SR-HMI Software
- 4.7 Instruction of SR-HMI
 - 4.7.1 To Modify the System Time
 - 4.7.2 To Modify the Parameter of the Counter
 - 4.7.3 To Modify the Parameter of the Timer
 - 4.7.4 To Modify the Parameter of the Analog
 - 4.7.5 Instruction of the Function Keys
 - 4.7.6 Switching between Running and the Stop State of the Machine
- 4.8 Meanings and Handling Methods of the Error Information on the SR-HMI

Chapter V Voice Module

- 5.1 Structure of Voice Module
- 5.2 Connection between Voice Module and SR Machine
- 5.3 Instruction of Voice Module
- 5.4 Applications of Voice Module
- 5.5 Instruction of Voice Software
- 5.6 Applications of Voice Software
- 5.7 Record Voice Message

Chapter VI Remote and Extension Module

- 6.1 Remote Module
 - 6.1.1 Structure of Remote Module
 - 6.1.2 Connection between Remote Module, SR Machine and Voice Module
 - 6.1.3 Instructions of SR-TC

6.2 Extension Module

- 6.2.1 Structure of Extension Module
- 6.2.2 Address Setup of Extension Module
- 6.2.3 Type and Wiring of Extension Module

6.3 Solid Diagram and Accessories of SR Series

Chapter VII Technical Parameter of SR Series

- 7.1 Technical Parameter of SR-12MRA/SR-22MRA
- 7.2 Technical Parameter SR-12MRD/SR-22MRD
- 7.3 Technical Parameter SR-12MTD/SR-22MTD
- 7.4 Technical Parameter SR-20ERA/SR-20ERD/SR-20ETD
- 7.5 Telephone Receiving and Transmitting Code and Voice Module
- 7.6 Remote Control
 - 7.6.1 Remote Receiving Module
 - 7.6.2 Remote Transmitter
- 7.7 General Technical Parameter of SR Series

Chapter VIII Application of SR

- 8.1 Multifunction Switch of the Illumination in Stairs, Halls and so on
- 8.2 Automatic Gate Control
- 8.3 Ventilation System
- 8.4 Illumination System for Display Window
- 8.5 Auto Water-supply System of the Water Tower

Chapter IX Guarantee

Chapter X Operation & Function of Programming Panel SR-WRT

- 10.1 Structure of SR-WRT
- 10.2 Display Interface and Function of SR-WRT
- 10.3 Function Interface of SR-WRT
- 10.4 Programming Operation of SR-WRT
 - 10.4.1 New Prg Operation
- 10.5 Edit Prg Operation
 - 10.5.1 Edit FB Operation
 - 10.5.2 Delete FB Operation
 - 10.5.3 Insert FB Operation
- 10.6 File Operation
 - 10.6.1 Rename Operation
 - 10.6.2 Copy Operation
- 10.7 Set up Operation
- 10.8 Test A B Operation
- 10.9 Programming Examples for SR-WRT

Part II Super CAD- Programming Software

Chapter I Installation and Uninstallation

- 1.1 Installation of Super CAD
- 1.2 Uninstallation of Super CAD

Chapter II General Introduction to Super CAD

- 2.1 Operation Interface
- 2.2 Edition Interface
- 2.3 Main Functions

Chapter III Operation Instruction and Function Block Stock

- 3.1 Function Instruction
 - 3.1.1 File
 - 3.1.2 Edit
 - 3.1.3 Controller
 - 3.1.4 Com
 - 3.1.5 View
 - 3.1.6 Option
 - 3.1.7 Help
 - 3.1.8 Search
- 3.2 Tool Bar
- 3.3 Function Block Stock
 - 3.3.1 Function Block Type
 - 3.3.2 Properties Setup and Action Demonstration of Function Block
 - 3.3.2.1 General Properties
 - 3.3.2.2 Special Properties

Chapter IV Basic Operation

- 4.1 Open File
 - 4.1.1 Open New File
 - 4.1.2 Open Old File
- 4.2 Edit Function Diagram Program
 - 4.2.1 Place Function Block
 - 4.2.2 Introduction to the Function Block Stock
 - 4.2.3 Function Block Table-list
 - 4.2.4 Edit Property of Function Block
 - 4.2.5 Build Wiring
 - 4.2.6 Delete Function Block or Wiring
 - 4.2.7 Simulate Running
 - 4.2.8 Save and Print
 - 4.2.9 Write, Read and Modify the Password